

Alternate method of installing iTronic devices in ML, GL and R Class with retractable CD Changer

Remove kick panel

Pull up the door sill with 'Mercedes Benz' written on it.



Remove the 3 screws holding the panel above the right hand side footwell

Pull off the door rubber and unclip the clips holding the front edge of the kick panel in place with a small flat screwdriver, and pull out - theres a clip in the middle that unclips as you pull.



Here you will see the body fibre optic connector connecting the fibre optics from the systems mentioned above which are in the rear of the vehicle to the head unit and CD changer.



You can use this fiber connector in lieu of the connector on the back of the radio or cd changer. Just follow the instructions on our videos, but use this connector instead. Also connect the power to a **CONSTANT 12V** (not switched!) supply and the ground (brown wire or black wire from the iTronic) to any metal body part or solid brown wire.