

THANK YOU FOR YOUR PURCHASE

PLEASE SEE

www.InCarTronics.com/support.htm

**for install manuals
and support videos**

For Information on the latest Laser Jamming products see

www.EuroJammer.com

Mercedes iTronic™ Quick Start Guide

Engage parking brake and move gear to D
Open ash tray, lift the center console cover



Pull ashtray out (fixed with two clips)





Remove fiber optic cable from holder by pushing tab over



remove CD changer or storage compartment (2 screws)



This will allow you to place the iTronic unit up behind the COMAND or down and to the left or right into the passenger footwell areas (behind the panels of course). If you wish more room, you can optionally slide the COMAND out by loosening ALL THE WAY the two screws in the bottom of the COMAND. They will not come out, but loosen them until they stop. The COMAND will slide right out.

If you have purchased the iTronic Bluetooth unit WITHOUT iPod support.

See video "iTronic BT Installation – WITHOUT iPod interface" on our website

If you have purchased the iTronic Bluetooth unit WITH iPod support OR an iPod ONLY unit.	See video "iTronic Installation – WITH iPod interface" on our website
Reverse the procedure above to reassemble	

WE WELCOME YOUR PICTURES FOR CARS THAT DIFFER FROM ABOVE

iTRONIC™ PLUG INSTALLATION

1. Using one of the included red wire taps, tap the orange wire from the iTronic to any 12v source.
2. Using one of the included red wire taps, tap the brown wire from the iTronic to any ground wire
3. If you have purchased the iTronic Bluetooth unit WITHOUT iPod support. Then see the video on our site called "iTronic BT Installation – WITHOUT iPod interface"
4. If you have purchased the iTronic Bluetooth unit WITHOUT iPod support. Then see the video on our site called "iTronic Installation – WITH iPod interface"
5. Place the module behind the COMAND or down one of the sides.
6. Reinstall COMAND radio

Mic:

1. Extend out the steering column to allow better access.
2. Unscrew fastening screws on the under steering cover column trim panel
3. Route the microphone wire under the steering column over to the left most dash trim area.
4. Route the wiring up the "A" pillar and place the Mic at the top of the pillar
5. Refit trim panel and adjust steering column.

PAIRING INSTRUCTIONS:

1. Turn on the car and make sure radio is on.
2. Wait 10 seconds
3. Start searching for the iTronic with your phone's Bluetooth search function
4. When asked for a password, enter 1234
5. Your done – this is a one time procedure. You may pair up to 4 phones with the unit. It will use only one phone at a time, of course.
6. See your car's owners manual for instructions on using the phone functions of your car.